



Keep your Proline Billiard Cloth performing like new with proper maintenance. Whether you play on Classic 303, Proform 505 or another Proline series, regular care helps preserve speed, accuracy, and appearance.

1. Brush Regularly

Use a soft, natural-bristle billiard brush to remove chalk dust and lint. Brush in one direction only, from the break end to the rack end. Avoid circular or side-to-side brushing—it can lift the nap and create uneven wear.

2. Vacuum Occasionally

Use a low-suction handheld vacuum or an attachment designed for billiard cloths. Gently pass over the surface after brushing to remove deep chalk buildup. Never use high suction or press down—especially important for unbacked cloths, which can stretch more easily.

3. Cover the Table

When not in use, always cover your table to protect from dust, UV light, and spills. A fitted, breathable cover is best for maintaining cloth tension and color.

4. Keep the Room Controlled

Maintain a stable room temperature and 40–60% humidity. Avoid direct sunlight, vents, and damp basements. Excess humidity can loosen cloth tension; dry air can make balls skid or play faster.

5. Practice Good Table Habits

Chalk cues away from the table to prevent chalk dust embedding into the weave. Don't lean, sit, or place drinks on the table. Inspect cue tips regularly—rough or broken tips can scratch the cloth. Avoid breaking with dirty or damaged cue balls.

6. Handle Spills Carefully

If liquid contacts the cloth, blot immediately with a clean, dry towel—never rub. If needed, use a slightly damp cloth with cold water only. Allow the area to air-dry completely before resuming play. Do not use cleaners or solvents—they can damage the fibers and backing.